

# Workshop Manual 01/2019 DE

AS-MOTOR Ride-On Flail Mower

AS 1040 YAK 4WD




Service Information

Adjustment, maintenance and repair instructions

# Manual AS 1040 YAK 4WD



## Index:

**Tipp:**  Über Mouse-Over-Click kann im Dokument navigiert werden - Click Seitenzahl und Click auf [www.as-motor.de](http://www.as-motor.de) um ins Inhaltsverzeichnis zurück zu kommen.

### Einleitung:

- Safety Instruction p. 3
- Online-Service-Portal „parts-and-more.org“ p. 4
- Maintenance work, Cleaning and Service p. 6

### Technical Data:

- Technical Data p. 7
- Maintenance schedule p. 8

### General:

- Tyre sizes p. 9
- Tightening Torque p. 11
- Faults p. 12

### Engine:

- Individual components p. 13
- Adjustment, regulation p. 14

### Drive line:

- Force progression p. 15
- Belt arrangement p. 16
- Belts tensioner p. 17
- Position arrangement p. 18

### Mower Deck:

- Belts changing p. 19
- Bearing mower deck changing p. 21
- Flail shaft remove p. 23
- Mower deck changing p. 25
- Innovations p. 28
- Flail shaft Force progression p. 39

### Drive line Transmission:

- Belt Hydrostat changing p. 31

### Hydrostat:

- Oil changing p. 33

### Drive lever:

- Arrangement p. 35

### Hydraulik:

- View from below p. 37
- Hydraulic shema p. 38
- Installation of the lines p. 39
- Axle drive p. 40

### Steering:

- Position Steering p. 41
- Adjusting the differential p. 42
- Front Axle p. 43
- Adjusting the pedals p. 44

### Saet:

- Adjustment screw p. 45

### Belt tensioner:

- Structure p. 46

### Elektric:

- Wire harness p. 47
- Electrical system p. 48
- Arrangement of the components p. 49

### Personal notes

p. 51

# Introduction

## Safety instructions




### Safety instructions

Only authorised AS-MOTOR Workshops are allowed to execute the activities cited in this manual.

Comply with the following instructions and the warnings in the respective sections, otherwise accidents with severe injuries can occur and/or the device can be damaged.

Prior to starting work:

- Place the device on a level and non-slip substrate.
- Only use ramps and hoists that are suitable for the device.
- Safeguard the device against rolling off and falling over.
- Let the device cool for at least 20 minutes.
- Close the fuel tap and the tank ventilation.
- Never place the device with petrol in the tank, inside a building where petrol fumes can come into contact with open fire or sparks.
- Do not inhale fuel fumes, they are harmful.
- Use gloves, particularly for tasks on cutting tools.
- Avoid skin contact with fuel and operating fluids.
- Caution when handling batteries: Battery acid is corrosive. Protect your hands and eyes from escaping fluid.
- Disconnect the battery via the negative terminal.
- This  symbol signals a warning. Failure to comply with the warning can result in accidents, injuries and damage!

Important note:

#### **ATTENTION** **WELDING TASKS**

Prior to performing welding tasks on the device unplug the plug connector from the control device (receiver). Always attach the welding device earth very close to the welding point. Otherwise there is danger of irreparably damaging the control device.

### Original spare parts

Important note: 

Only original AS-MOTOR spare parts ensure safety, keep the guarantee intact and protect against damage. Consequently only use original AS-MOTOR spare parts; do not use any imitation or counterfeit parts.

Installation of non-original parts invalidates the guarantee claim and the operating authorisation. Accidents with severe or fatal injuries can be the result.

All original wear parts, all original blades and many original spare parts bear the stamped AS-MOTOR logo, as well as the EXXXXX and/or G XXXXXXX part numbers.

# Introduction

## Online service portal "parts-and-more.org" (PAM)



## Online service portal "parts-and-more.org" (PAM)

For all tasks shown in the Workshop Manual the online service portal "parts-and-more.org" is your most important companion. It offers you the following functions for every single AS-MOTOR device:

- Exploded drawings of each assembly
- Spare parts lists for each assembly
- Modification information for parts
- Current availability (online stock) of spare parts
- Spare part ordering function
- Management of current shopping carts and older orders
- FAQ and general technical information
- Guarantee claims

Access to the online portal "parts-and-more.org":

Every official AS-Motor dealer has access to the online service portal via his customer number.

Login access to the system occurs via the website:

[www.parts-and-more.org](http://www.parts-and-more.org)

Access data is issued within one to two days after "Dealer first login" using the AS-Motor customer number.

After receipt of the access data (parts ID and password) you can log in via "Immediate login" and use all functions immediately.

For questions concerning "parts-and-more.org" please contact:

- [info@as-motor.de](mailto:info@as-motor.de) or
- [service@parts-and-more.info](mailto:service@parts-and-more.info)
- AS-Motor Germany +49 7973 9123-0

# Introduction

Online service portal "parts-and-more.org" (PAM)



Parts search

Language selection

Shopping cart

Device and assembly selection

Spare part function

Information – FAQ

Availability

The screenshot displays the AS-Motor online service portal interface. On the left, a navigation tree lists various product categories and parts. The main area shows an exploded view of a mower with numbered callouts (e.g., 22, 300, 304, 307, 309, 313, 315, 444). Below the exploded view is a parts list table titled "Stückliste: Messer mit Antrieb".

Pos	Art.-Nr.	Art.-Nr. (bisher)	Menge	Beschreibung	Info	Modell	Prg
305	G07865011	E06649	1 (1)	Passfeder			
306	G06925016	E11700	1 (1)	Riemenscheibennabe			
307	G06925008	E11698	1 (1)	Riemenscheibentrommel			
308	G06925009	E11699	1 (1)	Riemenscheibenhälfte			
309	G07838017	E03262	12 (10)	6kt-Schraube (10 Stk.)			
310	G07861004	E07213	3 (1)	Scheibe			
312	G07847015	E03928	2 (1)	Stützscheibe			
313	G06923004	E11694	1 (1)	Wickelschutzbecher			
314	G06923040	E41465	1	Ersetzt durch G06980016			
	G06980016	G06980016	1	Oberes Mulchmesser+Messerscheibe			
315	G07865031	E11695	1 (1)	Passfeder			

On the right side of the interface, there are several buttons and a message: "Der Warenkorb ist nur für reguläre Kunden nutzbar", "Anmelden", "Hinzufügen (max. 16)", "Standard", "Warenkorb download", "Bestellen", "Warenkorb Verwaltung", "Anfragekorb", and "Warenkorb download E-No.". Orange lines connect various parts of the interface to descriptive labels on the left and right.

Print function

Magnifying glass function

Complete overview

Parts – direct selection highlighted red

Spare parts list

Parts information  
Change notifications

# Introduction

## Maintenance tasks, cleaning and maintenance intervals




### Maintenance and cleaning (general information)

To ensure the full functionality, the safety and a long service life of the machine, regular maintenance and cleaning of the machine are essential.


All necessary activities and their intervals are listed on the following pages.

### Prior to maintenance

**Danger!**  Danger of injury if maintenance and cleaning tasks are performed when the engine is running. Only execute maintenance tasks when the engine is running if this is explicitly required.

Prior to all maintenance and cleaning tasks when the engine is at a standstill:

- Let the device cool for at least 20 minutes.
- Close the fuel tap and the tank ventilation.
- Disconnect the negative terminal of the battery.


**Warning!**  The device can tip or fall over and cause severe injuries.

The device can be lifted or tilted to execute maintenance, repair or cleaning tasks on the underside of the device.

- Only lift the device on a level substrate.
- Only use hoists and ramps that are suitable.
- Only attach hoists on the main frame, only the main frame can bear the weight.
- Safeguard the device against tipping over or falling.

- Stay out of the tipping area.

### Clean the device:

- Thoroughly clean the device after each use. Particularly the underside and the blade enclosure.
- Clean the air grille, engine cooling unit and engine.
- Clean the transmission housing and transmission fan.
- **Danger of fire!**  Particularly ensure clean parts on the exhaust system.
- For cleaning use brooms, brushes, damp cloths and wood or plastic spatulas.
- Do not clean with a high-pressure cleaner!
- Do not use any aggressive cleaning agents.

### Thorough visual inspection:

Check the following for safe operation of the machine:

- Nuts, bolts, screws, fuel lines, air filter for firm seat
- Ignition cable and ignition connector for damage
- Covers, protective cloths, muffler
- Tank, fuel tap, carburettor, engine, transmission, battery, hydraulic system for leaks

# Technical data and maintenance schedule

## Technical data



Technische Daten AS1040 YAK 4WD	
Einsatzbereich/ Application	0-30°C / 32-86°F
<b>Motor/Engine</b>	
Bauart/Design	2 Zylinder-4 Takt Motor
Hersteller/Manufacturer	Briggs&Stratton
Typ/Type	Vanguard, V-Twin; code: 386447 0414-G1
Hubraum/Displacement	627 cm <sup>3</sup> /627ccm
Leistung/ Power	15,5 kW /21,1 hp
max Drehzahl/max rpm	3000 /1min
Startvorrichtung /Starter	Elektr.
<b>Batterie/Battery</b>	12V 30Ah
Sicherungen/Fuses	Haupt/Main 25 A
Sicherungen/Fuses	rest 25A
<b>Fahrantrieb/Driveline</b>	Permanenter Allrad ,permanent FWD
Hinten/rear	Hinterachse m. Differentialsperre/ Rear Axle w diff loc.
Vorne/front	Pendelnd gelagerte Portalachse, 2 Hydromotoren und Königswelle/Pendulum-mounted gantry axis, 2 hydraulic motors and vertical shaft
Geschwindigkeit vorwärts/Speed foreward	0-6,8km/h / 0-4,22mph
Geschwindigkeit Rückwärts/Speed reverse	0-6,3km/h /0-3,91mph
Wendekreis/ Turning Circle	1,4m 55 inch
<b>Schneidwerk/Cutting</b>	Schlegel-Mähwerk ,56 Y-Schlegel/Flail mower w 56 Y-Flails
Schnittbreite/Cutting wide	100 cm /39,37 inch
Schnitthöhe/Cutting height	30-110 mm /1,18-4,33 inch
Transportstellung/Transport	120 mm 4,72 inch
<b>Maße und Gewichte / Dimensions</b>	
L/B/H	205/130/123 cm 80,71/51,18/48,43 inch
Gewicht/weight	337kg / 742,96 lb
<b>Füllmengen/Capacities</b>	
Kraftstofftank, Fuel	16 l /4,22 US Gal.
Motoröl/ Engine Oil	1,7l / 0,45 US Gal. 5W50 Öl/oil
Getriebeöl /Transmission	6,8 l / 1,8 US Gal. 5W50 Öl/oil
Geräuschpegel DIN EN 12733/ Noise level	
gemessener Schallleistungspegel /measured sound power level L/wa	102,6 dB
Schalldruck am Bedienplatz/Sound pressure at the operator station L/pa	92,7 dB
Vibrations -Emissionswert/Vibration emission value	
Hand-Arm Schwingungen/Hand-arm vibrations ah,w	1,1m/s <sup>2</sup> gemäß DIN EN 12733
Messunsicherheit/measurement uncertainty U	0,15 m/s <sup>2</sup>
<b>Reifen</b>	
Vorne/front	15x5.00-6 (included/enthält 0,5L Reifenpannenschutz/tyreprotect
Hinten/rear	18x9.50-8 ( included/enthält 1,0l Reifenpannenschutz/Tyreprotect

# Maintenance schedule

## Maintenance schedule

Hydrostatic oil change, same maintenance interval as AS 940 Sherpa.

The implementation can be found on page 33.



Group	Action	Service	
		A	B
Machine	Check for safe working condition (basic view)	■	▲
	Cleaning	■	
	Service		▲
Mower	Clean. See chapter Cleaning mower	□	
Fuel Tank, Fuel pipe	Check fuel level	■	
	Is the fuel cap closed	■	
Fuel	Check leaks and good condition		
Grill	Cleaning	■	▲
Cooling	Cleaning	■	▲
Ignition	check/Replace		▲
air filter	Service	■	■▲
Blade	Check for wear and damage. See chapter Checking the knife and flute shaft	■	▲
	change		▲
	Screw-on point Clean knife blade	■	
Blade brake	The brake works safely and the knife stops in 7 seconds	□	▲
Drive Lever	If the device is stationary when the lever is in neutral position when the footbrake is applied	□	▲
	Devices with foot brake: Does the lever go to zero when the foot brake is applied?	■	▲
Belt	Are the belts properly tensioned, with no cracks and in good condition?		▲
Cabels	Check function and ease of operation	■	▲
accelerator	check function	□	▲
Chassis und protection	Check for rust and cracks and check the welds	■	▲
	Are all guards and covers in place, properly attached and functional	■	▲
Decals	Decals readable	■	▲
Engine	Binding information See operating instructions for engine manufacturers	■	▲
	Check oil level (see operating instructions engine manufacturer)	■	▲
	Oil Change		▲
	Oil filter change		▲
Parking brake	check/Adjusting/change	■	▲
Brake	function of the brake	■	▲
Flammable material	Material remove	■	▲
Steering	check clearance	■	▲
Tyre	check Tyre and Tyre pressure	■	▲
Safty switch	seat, cutting height adjustment and travel drive		
Ignition lock	ceck function	□	▲
Hydrostat Transmissi	Check oil level	■	▲
	eliminate oil leaks		▲
	Oil change after 50h afterwards all 200h		▲
Battery	Check charge status		▲
A	Before and after each use		
B	Annually or every 50 h		
■	By the end user with the engine stopped		
□	By the end user while the engine is running		
▲	authorized workshop		




# General information

## Tyre sizes, wheel dimensions, tyre pressures 1/2




### Tyre pressures


A uniform and correct tyre pressure is essential for the following characteristics:

- Traction uphill
- Braking force downhill
- Suspension comfort
- Safety  : The tyre does not come off of the rim!
- Uniform mowing pattern

Rules: 

- Check the air pressure on a regular basis.
- Examine tyres and tyre flanks regularly for damage.
- Replace damaged tyres.
- Only use original AS-MOTOR tyres.
- Do not change tyre diameters or tyre sizes. This can damage the 4WD.

Tips / notes: 

- Inflate the tyres with our recommended tyre pressures. In our opinion, these pressures offer an optimum of suspension comfort and traction.
- High tyre pressures have a negative influence on suspension comfort and traction.
- Do not underrange the recommended tyre pressures. Tyres can come off of the rims. 
- Do not exceed the maximum tyre pressures.
- AS-Motor mowers come from the factory with a tyre pressure that is higher than the recommended pressure.
- Tyre sealant can prevent flat tyres. Particularly in tubeless tyres.
- Anti-puncture insert strips can prevent flat tyres.
- Pay attention to the running direction of the tyres, left / right for optimal traction.
- Slow pressure loss of a tyre indicates that there is a thorn in the tyre.
- Tubed tyres cannot be easily used without a tube.
- Next page: Overview TABLE "Wheels"

# General information



## Tyre sizes, wheel dimensions, tyre pressures 2/2

Model:	Front wheel (FW) / rear wheel (RW):	Tyre size:	Recommended air pressure:	Maximum air pressure:	Tread:	Tubed Tyres (TT) / Tubeless (TL):	Standard equipment / optional:
AS 1040 4WD	FW: RW:	15x5.00-6 18x9.50-8	<b>17 psi / 1.20 bar</b> <b>15 psi / 1.00 bar</b>	18 psi / 1.24 bar 24 psi / 1.65 bar	AS AS	TL TL	Series Series

### Tightening torque for wheel bolts / wheel screws:

- Rear wheels: M12 100 Nm (73.75 lb-ft)
- Front wheels: M8 40 Nm (29.50 lb-ft)

# General information


## Tightening torques for bolted connections 1/1



### Tightening torques

Correct tightening torques are important to ensure a solid connection of components and to avoid damage

Correct tightening torques are safety-relevant on rotating parts, in particular, like flails, belt pulleys and wheels.

The following tightening torques always apply for hexagon bolts, socket head screws with hexagon socket and standard thread in 8.8 quality: 

**Bolts with standard thread DIN quality 8.8**      **Bolts or nuts with under-head serrations**

Thread:	Width across flats:	Torque in Nm: (lb-ft)	Torque in Nm: (lb-ft)
M5	8	6 Nm (4.5)	8 Nm (5.9)
M6	10	12 Nm (8.6)	15 Nm (11.1)
M8	13	25 Nm (18.5)	35 Nm (25.9)
M10	17	55 Nm (40.6)	70 Nm (51.7)
M12	19	90 Nm (66.4)	120 Nm (88.6)

### Special tightening torques

In the tables on the following pages the individual torques are presented for essential, special and safety-relevant parts.

**Tip / note:** 

You will find the listed bolts / threaded fittings based on the position number (#XXX) in the exploded drawings of the respective assembly at parts-and-more.org (PAM). The position numbers are the numbers in circles on each part in the exploded drawing. In the parts list below the drawing the position number (Pos.) is also shown and cited by name.



# Engine

## Individual components



Oil drain plug  
Oil filter



rpm adjustment – accelerator  
cable  
From above



Engine earth



Fuel pump  
Oil filler neck




Shut-off valve – carburettor



Oil cooler  
Oil pressure switch (green  
cable)

# Engine

Adjustment, regulation




Final rpm adjustment  
by bending the lug

Idle by bending the stop

Final rpm 3600 rpm

Idle rpm

1600 +/- 100 rpm



Cable holder

Idle screw

Full-load adjustment

Idle stop

Regulator spring


Centrifugal force regulator (always regulates in the off direction)



Engine code

# Drive

## Force progression






# Force progression

## Belt arrangement



Drive belt for transmission G07857057



Drive belt for flail shaft  
G07857035


Angular gear unit

Drive belt for transmission  
G07857056




# Force progression

## Belt tensioner



Belt tensioner for transmission




Belt for the transmission  
From above



Belt tensioner for reduction  
gearing  
View from the outside




Belt tensioner for reduction  
gearing – view into the frame



# Force progression

Position arrangement




# Belt drive


## Replacing the mower unit V-belts (1/2)




Take off the cover to the right in the direction of travel → pay attention to the spacer sleeves



Remove the lever of the blade brake → unhook spring




Unhook Bowden cable of the mower unit coupling



Unscrew bolt and detach belt guide



Unscrew screw → slide bolt upward



Remove belt guide from the front





# Flail mower unit

## Replacing the mower unit V-belts (2/2)



Take off belt

Installation in the reverse  
sequence



When installing the (if required)  
belt tension lever, ensure that  
the sliding discs are correctly  
seated → sliding disc must rest  
on the bearing

# Flail mower unit

## Replacing the bearing of the flail shaft (1/2)




Preliminary tasks, see "Replacing the mower unit V-belts"




Loosen the bearing block, twist and remove with a puller



Detach belt pulley




Remove circlip and knock out the bearing




Detach belt pulley from the shaft with a puller → pay attention to the feather key

Installation in the reverse sequence



# Flail mower unit

## Replacing the bearing of the flail shaft (2/2)



Detach safety bracket




Twist and pull off bearing block  
→ knock-out bearing



Remove battery → first disconnect the negative terminal



Detach cover



Installation in the reverse sequence




# Flail mower unit


## Remove flail shaft (1/2)



Preliminary tasks, see "Replacing the flail mower unit V-belts"



Pull off the belt pulley




Remove safety bracket and battery



Detach bearing block



Detach belt pulley



Detach cover on the left side

# Flail mower unit


## Removing the flail shaft (2/2)




Twist bearing block and pull it off



Remove flail shaft by moving it downward and to the left



Detach bearing guide and skid



Installation in the reverse sequence → pay attention to the install position of the bearing guide






# Flail mower unit


## Removing the flail mower unit (1/3)




Detach belt cover → pay attention to the spacer sleeves




Remove safety bracket and battery → first disconnect the negative terminal



Detach Bowden cable and remove eye



Unscrew bolts and remove the cover of the drive shaft



Pull Bowden cable through the spring package




Take-off V-belts

# Flail mower unit


## Removing the flail mower unit (2/3)



Detach belt pulley → inner screws



Unscrew the screw of the height adjustment element



Bring the flail mower unit into transport position and unhook the springs on both sides



Unscrew the screw of the mower unit holder → counter with AF 27



Offload flail mower unit → prop it up




Unscrew the screw of the mower unit holder → counter with AF 27

# Flail mower unit

## Removing the flail mower unit (3/3)




Lift the machine with a crane



Pull the flail mower unit to the side

Installation in the reverse sequence






# Flail mower unit

Innovations



Cleaning nozzle connection



From S/N 033118060032  
New bearing installed




Flail shaft installed



Screw must completely fill out  
the nut


# Flail mower unit

Force progression



# Force progression

Position arrangement





# Belt drive hydrostatic transmission


Replacing the belt drive of the reduction gearing and hydrostatic transmission  
(1/2)



Detach cover → pay attention to the spacer sleeves



Detach belt pulley → inner screws




Detach the blade clutch cable



Prop up vehicle right rear and take off rear wheel




Take off V-belt of the mower unit drive



Detach belt cover

# Belt drive hydrostatic transmission


## Replacing the V-belt of the reduction gearing (2/2)



De-tension the belt tensioner by hand and take off the belt



Detach belt cover




Installation in the reverse sequence



De-tension the belt tensioner by hand and take off the belt



Take off the fan grille




Installation in the reverse sequence → when installing the fan grille pay attention to the sealing lip on the air duct




# Hydrostatic oil change


AS 1040 YAK 4WD




- Drive lever in Neutral Position stellen (A).
- remove cap oil expansion tank (B).



Remove cooling protektion and the belt cover




- Put the oil pan under the rear axle (about 4.5 liters)
- Remove underrun protection
- Unscrew cover (3/8 inch) Remove oil filter



- Release oil vent screw (D)
- Unscrew both oil drain plugs (SW 14) and oil into the Run catch basin. (about 4.5 liters)



When venting the front axle, the rear of the machine must be increased by 450 mm (17,717 inch )



Necessary filling edge on the container only when filling and bleeding the front axle.

# Hydrostatic oil change

AS 1040 YAK 4WD



Remove dirt on the plug of the front axle Unscrew the sealing plug of the front axle



The following work must be performed on the right and left stub axles:

Place oil drain pan under the steering knuckle.

Remove dirt on the bleeding screw (") SW 10 and unscrew it.


Unscrew oil drain plug (1) SW 12 (approx. 1.2 liters per side)

Important NOTE:


Heat the fresh fully synthetic oil 5W 50 to 25 ° C. This significantly reduces the filling and venting time and reduces the risk of air in the hydrostatic drive. The device may only be started with a fully vented hydrostatic drive. If the hydrostatic drive is not fully vented, it will be damaged.

# Drive lever

## Arrangement



# Drive lever




4 friction discs (419) hold the drive lever in position (cruise control function)

Brake must be adjusted in such a manner that at activation of the pedal, the lever always goes automatically into the middle position.



# Hydraulic system

View from below




# Hydraulic system

## Hydraulic system diagram AS 1040 YAK 4WD



Rear axle


6.8 l fully-synthetic engine oil 5W-50




Front axle

# Hydraulic system

## Installation of the lines



Transmission rear axle



Front axle



Oil change same as for AS 940


# Hydraulic system

## Axle drive




The axle drive is powered with the return oil of the rear axle. This means that in normal operation a variable all-wheel drive is present. As soon as one wheel of the rear axle spins, the front axle gets pressure from the rear axle and thus absolute all-wheel drive.

In addition, the front axle has a compensation for cornering, to prevent deformation of the front axle. The right front wheel is driven by a servomotor. When cornering this motor runs faster or slower. The servomotor is activated via a linkage. It must be ensured that the linkage is not bent. This can cause a blocking of the front angle.



Double – engine unit of the front axle






# Steering

Position of the steering column lever in the toothed segment



# Steering


Adjusting the differential



Adjust lever vertically to the axle

# Front axle

## Function Damper



The pendulum path is visually limited by the damper G90430005 on both sides with each 1 cm. The damper consists of a PE plastic, as in the automotive sector as a stop vapors is used. At the stop of the axle on the damper, this cause a braking and damping of the pendulum path. This keeps the machine stable on uneven terrain.



Elasticity as additional travel

Clearance between axle and damper



# Differential / brake lever

## Adjusting the pedals




### Differential

Adjust in such a manner that the cable has no play, and so that the wheels block the approximately 1 cm in front of the end stop. This ensures that the tappets completely engage in the transmission

### Brake lever


Play on the cable approx. 6-8 mm – cable should be adjusted in such a manner that at ½ distance the drive lever goes automatically into the brake position (middle)







# Seat springs

Adjustment screw



# Belt tensioner



## Structure



All belts – drive, transmission / flail shaft – are automatically brought to the correct tension via an automatic belt tensioner


Structure: sleeve (146), spring (148), linkage (144), piston (145)

For repair ensure that all moving parts can move freely  
1 cm between sleeve and joint head



# Electrical system


## Wiring harness





# Electrical system


## Electrical circuit diagram – AS 1040 YAK 4WD





# Electrical system

## Arrangement of the components




Central earth point  
Frame next to the battery



Orange shut-off valve  
carburettor  
Green oil pressure switch




Micro switch  
Drive lever



Fuses  
Ignition lock




Micro switch  
Blade clutch




Generator regulator 12 V

# Electrical system

## Arrangement of the components



Central connector – engine



Starter relay at the bottom on the engine on a rubber bearing  
If the rubber of the bearing is damaged, replace the bearing

Personal notes



---

---

---

---

---

---

---

---

---

---



## **AS-MOTOR Germany GmbH & CO.KG**

Ellwanger Strasse 15

74424 Bühlertann, Germany

[www.as-motor.de](http://www.as-motor.de)

[info@as-motor.de](mailto:info@as-motor.de)

[www.parts-and-more.org](http://www.parts-and-more.org)

All rights reserved. Reprint, duplication or publication without approval are prohibited.  
Subject to technical changes.